

Getting Started

Control your home heating by setting up **Climote** to work with your **Amazon Echo** devices.



Connecting Climote to Alexa

- 1 Set up your Amazon Echo devices
- 2 Select Skills in the Alexa App Menu and search for Climote Heating Control - select it and then click enable
- 3 Sign into your Climote account using your email address, Climote device number and optional password (your Climote engineer sets this up with you)

And that's it, once your Climote skill is enabled you'll be ready to control your Climote Heating Control with Alexa.

Don't forget:

Alexa works using a cloud-to-cloud connection so you'll need a working WiFi connection to communicate with your Climote Heating Control over Alexa.

Need some help?

If you need some help or have any questions about your Amazon Echo devices, visit the Help section in the Alexa App. For more information on enabling your Climote skill see www.Climote.ie/alexa

amazon alexa **Common Commands**

Here is a handy list of common commands you can use to control your heating with Climote and Alexa.

Command *Alexa, open Climote.*

What happens Opens the Climote app and asks what you would like to do? Boost bedroom etc...

Command *Alexa, ask Climote to turn on the heating.*

What happens The heating will be turned on for 1 hour.

Command *Alexa, ask Climote to turn off the heating.*

What happens The heating will be turned off.

Command *Alexa, ask Climote to boost (hot water).*

What happens Hot water will be turned on for 1 hour.

Command *Alexa, ask Climote to cancel boost.*

What happens All current boosts will be cancelled.

Command *Alexa, ask Climote to check my heating status.*

What happens Gives you a quick overview of the status of your heating. For example, living zone is on and temperature is 21°C.

Command *Alexa, ask Climote for help.*

What happens Alexa will run through a short list of commands that you can do with your Climote skill for Alexa and prompt you for a follow up action.

If your home has multiple heating zones, you can also use the following commands

Command *Alexa, ask Climote to boost (living) for (2hrs) & (water) for (1hr).**

What happens The living zone will be turned on for 2 hours and the water zone will be turned on for 1 hour.

Command *Alexa, ask Climote to hold (bedroom) for (3hrs).**

What happens Will place a hold on any scheduled-on times in the bedroom zone for the next 3 hours.

Command *Alexa, ask Climote to set the (bedroom) thermostat to (21°C).**

What happens Will set the target temperature for the bedroom zone to 21°C.

*Only applicable for homes with multiple heating zones